

Keyboard issues

Keychron c2 keyboard - volume button not working properly?

Press **Fn + X + L (for ~4 seconds)** to enable function lock

<https://www.keychron.com/pages/c2-keyboard-user-manual>

Revision #1

Created 7 April 2026 07:36:00 by Conor

Updated 7 April 2026 07:37:07 by Conor